
BMW 4er-Reihe G22

Coupé

07/2020







	Airbag		Stored gas inflator		Seat belt pretensioner		SRS control unit		Pedestrian protection active system
	Gas strut / Preloaded spring		High strength zone		Battery low voltage 12V/48V[1]		Fuel tank content gasoline/ethanol		

[1]Switch off the ignition to avoid the risk of an electric arc when disconnecting.

© 2021 BMW AG Munich, Germany

1. Identification / recognition

2. Immobilisation / stabilisation / lifting

Immobilization

1. Press the "Start / Stop" button to turn off the vehicle



2. For automatic transmission: Press the "P" button




2. For manual transmission: Shift to first gear




3. Pull parking brake upwards



Stabilization points/lifting points






3. Disable direct hazards / safety regulations

4. Access to the occupants

Interfaces

1 Interfaces for removing the roof
2 Door lock
3 Door hinges



5. Stored energy / liquids / gases / solids

Identification of the high-voltage battery



Identification of the remaining high-voltage components





Fuel

Diesel engine: Diesel DIN EN 590
Gasoline engine: Gasoline 91 – 100 research octane number

6. In case of fire

Even after a fire, there is an electrical hazard. Injury hazard!
Use personal protective equipment identical to the equipment used for conventional vehicle fires.

7. In case of submersion

Vehicle partially or completely submerged in water

After the vehicle has been salvaged from the water, disconnect the low-voltage battery (negative terminal).

8. Towing / transportation / storage





9. Important additional information

The maximum amount of equipment for the vehicle is presented in this document.